

ТАБЛИЦА СОВМЕСТИМОСТИ ВСТАВОК И РЮКЗАКОВ

| Вставки | | | | Рюкзаки | | | | | | | | | | | | | | | |
|--|--------------------------|--------------------------|-----------------------------|--|--|--|-------------------------------|--------------------|-------------------------------|-------------------------------|--------------------|--------------------|-------------------------------|--|--------------------|--------------------|--|--------------------|----|
| | | | | Action X | | | | | Explore V2 | | | Urban Explore | | | Side Lite | Side Street | | Sidecountry | |
| | | | | X25 | X30 | X40 | X50 | X70/HD | 25 | 30 | 35 | 20 | 25 | 30 | 22 | 22 | 28 | 28 | 32 |
| Артикул | Наименование | Внешний размер ВхШхГ, см | Внутренний размер ВхШхГ, см | 520-118 520-119 520-120 520-121 | 520-125 520-126 520-127 520-128 | 520-132 520-133 520-134 520-135 | 520-139 520-140 520-141 | 520-144 520-145 | 520-146 520-152 520-153 | 520-147 520-156 520-157 | 520-160 520-161 | 520-180 520-181 | 520-182 520-183 520-185 | 520-370 520-371 520-372 520-373 | 520-380 520-381 | 520-382 520-383 | 520-350 520-351 520-352 520-353 | 520-354 520-355 | |
| 520-222 | Small Mirrorless | 29x24x13 | 27x22x12 | ● | ● | ● | ● | | ● | ● | ● | ● | ● | | | | | | |
| 520-213 | Medium Mirrorless V2 | 29x29x13 | 27x27x12 | | ● | ● | ● | | | ● | ● | | ● | | | | | | |
| 520-223 | Large Mirrorless V2 | 39x29x13 | 37x27x12 | | ● | ● | ● | | | ● | ● | | ● | | | | | | |
| 520-091 | Small DSLR | 12x29x17 | 10,5x27x16 | | ● | ● | ● | | | ● | ● | | ● | | | | | | |
| 520-214 | Medium DSLR V2 | 29x29x18 | 27x27x17 | | | ● | ● | | | | ● | | | | | | | | |
| 520-245, 520-215 | Large DSLR V3 | 42x29x17 | 40x27x16 | | | ● | ● | | | | ● | | | | | | | | |
| 520-246, 520-216 | Large DV V2 | 42x31x21 | 40x29x20 | | | | | | | | | | | | | | | | |
| 520-247, 520-217 | Extra Large DV V2 | 50x31x21 | 48x29x20 | | | | | | | | | | | | | | | | |
| 520-248 | XXL DV | 57x31x21 | 55x29x20 | | | | | | | | | | | | | | | | |
| 520-450 | X-Small Mirrorless XS25 | 21x26x13 | 19x24x12 | ● | ● | ● | ● | | ● | ● | ● | ● | ● | | | | | | |
| 520-451 | Small Mirrorless S25 | 30x26x13 | 28x24x12 | ● | ● | ● | ● | | ● | ● | ● | ● | ● | | | | | | |
| 520-452 | Large Mirrorless L25 RST | 45x26x13 | 43x24x12 | ● | ● | ● | ● | | ● | ● | ● | ● | ● | | | | | | |
| 520-453 | Mirrorless XL30 RST | 48x28x13 | 46x26x12 | | ● | ● | ● | ● | | ● | ● | | ● | | | | | | |
| 520-454 | DSLR XL40 RST | 52x28x16,5 | 50x26x15,5 | | | ● | ● | ● | | | | | | | | | | | |
| 520-455 | DSLR XL50 RST | 55x28x16,5 | 53x26x15,5 | | | | ● | ● | | | | | | | | | | | |
| Сумки-вставки Top Loader | | | | | | | | | | | | | | | | | | | |
| 520-400, 520-401 | Small | 26x17x15 | 21x15x12 | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| 520-402, 520-403, 520-404, 520-405 | Medium | 26x26,5x15 | 21x24,5x12 | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| 520-406, 520-407 | Large | 26x32x15 | 21x30x12 | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| Сумки-вставки для дронов размещаются в верхнем отсеке | | | | | | | | | | | | | | | | | | | |
| 520-472 + 520-473 | Drone Pro | 26x18x16,5 | 24,5x16,5x15 | | | | | | | | ● | | | | | | ● | ● | |
| 520-470 + 520-471 | Drone Mini | 26x18x10 | 24x17x8 | | ● | ● | ● | ● | | | ● | | | ● | ● | ● | ● | ● | ● |